

CLAIR LIGHTING SUPER MAGIC BALL

User's Manual



Please read this user manual before using this product

Thank you for use our LED series stage light, to protect this product work safely, please check the voltage carefully before power on.

> Features:

Voltage: AC100V-240V 50/60Hz

Power: 40W

Light source: 9pcs*12W RGBW 4in1 LED

Dimmer: 255 level linear dimmer

Four operation mode: Auto, sound active, DMX and Master/slave mode

Channel: Addr512 (6 CH)

Size: 280*280*330mm

Weight: 1.5kg

> LED display and function:

MODE	UP	DOWN	ENTER	FUNCTION
A001---A512	+	-	save	DMX512 mode(slave mode)
CH06	+	-	save	Channel select
AU01	+	-	save	Auto mode(01 fast auto move)
SNON-SNOF	+	-	save	Sound mode(ON,OFF-DMX mode)
RPON-RPOF	+	-	save	Pan motor anticlockwise/clockwise rotation select
RDON-RDOF	+	-	save	LED display upright/inverted display select
DFON-DFOF	+	-	save	Restore factory defaults

> When slave mode, the master could operate Auto or Sound mode.

> **Channel:**

Channel	Value	Function
CH 1	0----127	Pan position 0-540°
	128--190	Pan position
	191--195	Pan off
	196--255	Pan position
CH 2	0----255	Pan/Tilt speed control (0 fast---255 slow)
CH 3	0----255	DIM (0-100%)
CH 4	0----255	Stroboscopic (0 slow---255 fast)
CH 5	0----029	LED off
	030--059	R dimmer
	060--089	G dimmer
	090--119	B dimmer
	120--149	W dimmer
	150--179	RGBW dimmer
	180--255	RGBW dimmer (180 slow---255 fast)
CH 6	0----009	From CH1-5 control brightness
	010--090	Fast auto move mode
	091--170	Slow auto move mode
	171--250	Sound mode
	251--255	REST

> **Warning:**

This product has watchdog program, please do not open main board by yourself, if it happens watchdog protection by human factor, it won't within the warranty period.

Packing spare parts:

spare parts	Q'ty
Power cable	1pcs
User manual	1pcs
Signal cable	
warranty card	